QUICKSTART

EB 30/1

Warning

These are only brief instructions! Please read and comply with these instructions prior to using or servicing your appliance.

The non-compliance of the operating and safety instructions may lead to damages of the appliance and to dangers for the operator and other persons.

Start up

1

A **B**

A Press the unlocking button of the battery and remove the battery.

B Connect the battery to the charger using the charging cable or rather insert the battery in the charger.

2

A **B**

A Insert the battery into the intake and lock it.

B Switch on the appliance; press the on/off foot switch to do so.

Operation

1

A **B** **C**

A Loosen the handle and pull out the strut to the desired working height; turn the handle to the correct position and tighten using the turning handle.

B Lock telescope strut on the side:
Activate the lock, then move it down and lock it in.

C The Cardan joint can be locked when cleaning high-fiber carpets to prevent the brush head from moving from side to side. Advantage: The brush head can be moved in straight paths.

2

A **B**

A Unlock telescopic strut:
Activate the lock, then move it up and lock it in.

B The Cardan joint can be unlocked again when cleaning smooth surfaces in order to allow the brush head to move more flexibly.

Finish operation

1

A **B**

A Switch off the appliance when finished.
B Unlock the dirt container and remove it. Empty dirt container after each cleaning. Insert and lock into place the dirt container.

2

A **B**

A Press the unlocking button of the battery and remove the battery.
B Charge the battery.

Maintenance and care

	daily	monthly	Kärcher Customer Service

1

A

A Press the unlocking button and remove the brush roller.

2

A **B**

A Remove wound up hair using a knife or scissors by moving the knife along the defined cutting edge of the brush roller. Remove loosened hair from the brush roller.
B Insert the cleaned or new brush roller and check the proper position.